
R	E	1

PLOT #	TYPE	PV POSITION
2	SEMI-DETACHED	TO REAR
3	SEMI-DETACHED	TO REAR
6	SEMI-DETACHED	AS SHOWN
8	SEMI-DETACHED	AS SHOWN
10	SEMI-DETACHED	AS SHOWN
16	SEMI-DETACHED	AS SHOWN
18	SEMI-DETACHED	AS SHOWN
20	SEMI-DETACHED	TO REAR
21	SEMI-DETACHED	TO REAR
24	SEMI-DETACHED	AS SHOWN
25	SEMI-DETACHED	AS SHOWN
28	SEMI-DETACHED	TO REAR
29	SEMI-DETACHED	TO REAR



FRONT SCALE: 1:100




FLOOR DRAIN UNDER BATH FOR FUTURE LEVEL SHOWER

IN DWELLING

UNLESS PROVIDED ELSEWHERE

FIRST FLOOR SCALE: 1:100



GROUND FLOOR SCALE: 1:100



REAR SCALE: 1:100

